

JWELL SAFETY PRECAUTIONS LEAFLET ENGLISH

INSTRUCTIONS FOR USE & STORAGE

This electronic cigarette/ vaporiser and its accessories (or any relevant products) are to be used with e-liquids only. Please read the following points before using for the first time.

Read the instructions for use and the technical information in detail. 'Atomisers' and 'tanks' are wearing parts. 'Coils' and 'wicks' (if replaceable) should be replaced regularly (when in use with e-liquid).

To clean the e-cigarette, remove the atomiser from the battery and clean the tank with a dry or lightly moistened cloth. Ensuring that the battery is kept dry at all times. The wick/ coil cannot be cleaned and must be kept dry.

To charge the battery, use the charging cable included with the device. We advise against charging the battery too rapidly.

Do not store this product in an environment susceptible to high temperatures or high humidity. Do not expose the product to prolonged direct sunlight.

CONTRAINDICATIONS

Those persons falling under the categories listed below should not use electronic cigarette products:

- children and adolescents (this product is designed for adult use only)
- pregnant or breastfeeding women
- persons suffering from respiratory illnesses or from allergies to any ingredients. The e-liquids used in this e-cigarette contain glycerine; glycerine can induce hyperglycaemia or glycosuria amongst those suffering from diabetes. E-liquids also contain flavourings which can trigger allergies.
- persons suffering from cardiovascular illnesses or diabetes
- persons taking antidepressant medication or asthma medication
- The use of electronic cigarettes is not recommended for non-smokers.

SAFETY

This product can be used with e-liquids containing nicotine. Nicotine is an addictive substance, and its consumption is not recommended for non-smokers. If you wish to reduce or stop your consumption of nicotine, contact your doctor or pharmacist. Keep out of reach of children and pets.

Nicotine is an addictive and toxic substance which can enter the body through inhalation, ingestion or through contact with skin. Nicotine can cause headaches, stomach pains, drowsiness and nausea and can affect heart rate and blood pressure. Nicotine increases the risk of hypertension and heart attack. When inhaled, nicotine can affect the functioning of the respiratory system. Direct ingestion of nicotine is toxic.

In rare cases, the use of this product can trigger allergic reactions and respiratory tract irritation, and can affect lung capacity and general health. The use of electronic cigarettes, e-liquids and e-cigarette accessories is solely at the risk of the user. If you or anyone around you experiences any unwanted effects, cease using this product and consult a doctor if necessary.

In the event of accidentally dropping or exposing this product or any of its accessories to impact, ensure that the product is still functioning safely before resuming use. Check that no e-liquid is leaking from the product and that the mouthpiece is intact and has no sharp edges. If the electronic cigarette is fully intact, you may resume use. If there are any cracks or deformations visible, cease using the product. Any and all repairs should be undertaken solely by the manufacturer. For hygiene, always keep each element of your e-cig clean, particularly the mouthpiece and tank. Stop using the e-cig if the tank is empty or nearly empty, and refill before resuming use of the device. This applies equally in the event that a change in taste is detected. If this is the case, clean the tank and replace the wick (coil).

If e-liquid comes into contact with your skin, wipe away immediately and wash the area thoroughly with clean water.

If you inadvertently swallow e-liquid, contact a poison control centre. If you feel unwell or experience pains, vertigo or nausea whilst using this product, cease use immediately. If symptoms persist after discontinuing use, contact a doctor. In case of emergency, call the emergency number.

TECHNICAL GUIDE

- Your battery should be in good condition and fully charged for optimal results. Insufficient battery power will produce insufficient heating of the e-liquid, which can lead to e-liquid discharging into the mouth.
- Do not draw too strongly on the device or the e-liquid will not have time to heat sufficiently and to vaporise, returning instead to its liquid state. In this event, rinse your mouth thoroughly with water.
- Your electronic cigarette is not designed for continuous use. It is equipped with a safety function that cuts battery power when the device becomes too hot; in this case the device enters an error state. YOU MUST wait 1 minute before using the device again. Failure to follow these instructions could result in serious burns if heated e-liquid enters the mouth. Overheating of your electronic cigarette can cause liquid to flow into the battery, damaging the device.
- To avoid breaking the electronic cigarette or firing the device permanently, do not press too firmly on the power switch
- Do not tighten the atomiser too firmly onto the battery; this can damage the device.
- Do not store your device in a bag without ensuring it is adequately protected and secure. Ensure that the device is powered off when not in use.
- Your electronic cigarette must not be cleaned with soap or with wa-

ter and must not be dried in a dishwasher or microwave oven. You must follow the instructions set out in "Maintaining your electronic cigarette".

- Never attempt to open the battery; this can result in 'venting' and risks serious burns.
- To avoid risk of electrocution, NEVER dismantle the charger or USB adapter.
- Do not install wicks or coils in your atomiser that are not approved by JWell.
- When not using your e-cigarette, remove the battery from the atomiser.
- Keep e-liquid out of reach of children.
- Do not attempt to manufacture your own e-liquids nor to add flavourings to your e-liquid.
- Only use JWell e-liquid, made in France and specifically designed for use in our electronic cigarettes for enhanced flavour and performance.
- When travelling by plane, remove the tank and, if full, store upside down to avoid leakage due to cabin pressure.

JWELL CANNOT BE HELD RESPONSIBLE FOR ANY ABUSE OR NON-COMPLIANCE WITH THESE INSTRUCTIONS. NO GUARANTEE IS GIVEN IN THE EVENT OF NON-COMPLIANCE WITH THESE INSTRUCTIONS OR OF INAPPROPRIATE USE.

FAQ

Your battery is not holding charge, or is not charging:

- The electrical contacts and the battery screw are dirty. See "Maintenance".
- Your charger is broken.
- End of battery's lifespan (a battery can be recharged approximately 300 times over its life).

Your battery is firing but no vapor is being produced:

- Check that the wick/ coil/ clearomiser is correctly screwed onto the battery
- Clean the battery screw and the atomiser/ clearomiser with a clean towel and an alcohol-soaked cotton swab.
- If the atomiser/ clearomiser still does not function, the internal coil may be burnt and should be replaced.

You experience a burnt taste when vaporising:

- it is likely that your atomiser/ clearomiser has not been correctly primed.
- Check the level of e-liquid in the atomiser or clearomiser.
- If there is sufficient liquid still within the tank, tilt the device several times.
- If the burnt taste subsides, visit your nearest JWELL store or use our online service.

Problems with draw:

- the airflow is insufficient
- Remove and reattach the atomiser without over-tightening- adjust the air inlet (if present).
- If the problem persists, contact your nearest JWELL store or use our online service.

Liquid is leaking from the atomiser.

- Ensure that the quantity of e-liquid has not exceeded the maximum fill level. Ensure that liquid is refilled into the correct area of the device.
- Cease using the e-cig continuously, if applicable, and do not expose it to extreme heat.

Liquid is leaking from the air inlet:

- Do not draw too strongly on the device; take long, gentle puffs.
- The battery is insufficiently charged- vaporisation is not occurring correctly: recharge your battery or adjust the battery power.
- Clean and dry your atomiser before resuming use.

Your e-cigarette suddenly stops functioning during inhalation:

- Your e-cig should not be used continuously; an inbuilt safety feature prevents your device from firing continuously for longer than 10 seconds.

ATTENTION: If your device is refillable, wait several minutes for the e-liquid to absorb into the wick after refilling to prevent damage and to avoid a burnt taste resulting from an unprimed wick.

J WELL France

21, Boulevard Ney
75018 Paris
FRANCE
+33 1 44 65 38 70
contact@jwell-pro.com